

# QUICK REFERENCE GUIDE TO THE 3200 PANEL

## **To Arm:**

Wait for solid **green** light on keypad and system ready. Enter your code followed by the **ON/OFF** key.

## **To Disarm:**

Enter your code followed by the **ON/OFF** key.

Note: If your code does not work the first time or if you enter the wrong code, press the **RESET** key, then re-enter your code.

## **Silencing an Alarm:**

If the alarm trips, you can silence the alarm by entering your code, press the **ON/OFF** key, then press the **RESET** key to clear the display

## **Bypassing a Single Zone when Arming:**

Press the zone number that you want to bypass then the **BYPASS** key.

\*If a code is required for bypassing, you must enter your code, then **BYPASS** then the zone number you want to bypass, then **BYPASS**

NOTE: ONCE YOU ARM THE SYSTEM WITH A ZONE BYPASSED, THAT ZONE WILL REMAIN BYPASSED UNTIL THE SYSTEM IS DISARMED. IF YOU WISH TO BYPASS THE ZONE WHEN YOU RE-ARM THE SYSTEM, YOU WILL HAVE TO BYPASS THE ZONE AGAIN.

## **Bypassing All Programmed Interior Zones when Arming:**

Press **INTERIOR** key, then enter your code and the **ON/OFF** key

## **Removing a Bypassed a single Zone:**

Repeat the step for bypassing the zone

## **Panic Button:**

To sound the siren, press the \* and the 9 button at the same time. An alarm will also be sent to Central Station and the police will be dispatched.

## **Silent holdup:**

Disarm the system by entering 66, followed by your code, then **OFF**. A silent alarm will be sent to Central Station and the police will be dispatched.

## **Mistakes:**

If you make a mistake entering your code, simply wait five seconds for the keypad to clear then re-enter your code

## **Reminder:**

If you activate either the Panic or Silent holdup feature, Central Station will immediately dispatch the police and will not call the premise. If you accidentally activate either of these, you must call Central Station with your account number and passcode to cancel the dispatch.

**Cancel an Alarm:**

If you accidentally trip your alarm and need to cancel, call the monitoring company and give your account number and passcode. You cannot cancel an alarm if you do not have the correct passcode.

**Service:**

If you need service on your system you can call 1-800-570-6478.

**AC POWER FAIL/E01-00 SERVICE**

Power Failure - Is there a general power outage? If not:  
Check power transformer (black square box plugged into outlet near panel)  
Check for blown fuse or circuit breaker

**LOW BATTERY/E02-00 SERVICE**

Battery below 11 volts – Usually due to AC power failure or Alarm  
Will automatically recharge after AC power restore  
If not recharged within 24 hours, it needs to be replaced

**COMM FAIL/E03-00 SERVICE**

Unsuccessful communication to central station – Is phone line working?  
If not: Notify your phone carrier of the problem  
If so: Call the Monitoring company  
Give them your account number and password  
Ask them to put your system on test  
Trip your panic alarm (see directions above)  
If this does not clear the trouble, call 1-800-570-6478 for service

**WIRELESS LOWBATT/E05-NN SERVICE**

Wireless transmitter low battery (NN = receiver number)  
Call the Monitoring company  
Give them your account number and password  
Ask them to put your system on test  
Remove the transmitter cover and replace battery

**SYSTEM TROUBLE/E18-NN SERVICE**

Key fob low battery (NN = key fob transmitter number)  
Call the Monitoring company  
Give them your account number and password  
Ask them to put your system on test  
Remove the key fob cover and replace battery

**SYSTEM TROUBLE/E41-NN SERVICE**

Trouble condition on a Fire Zone  
Press the **RESET** button to silence the sounder.  
Correct the trouble, then press the **RESET** button again.

**ANY OTHER MESSAGES: CALL 1-800-570-6478 FOR SERVICE**